

Converting VHS to DVD Format:




1. Turn on both the VCR and PC.
2. Make sure the Elgato video capture cables are connected.
3. Put VHS tape in VCR. Be sure it is at the beginning of tape.
4. Double click on Elgato video capture logo on taskbar.
5. Fill in information on first screen: Name of video and approximate duration.




(be sure to note what you name it so you can find it in the Movie folder later.)

Click to continue.




6. Decide on aspect ratio (standard 4:3 or wide screen 16:4)
7. Sound cable check is next. Click continue.

8. Mute the sound while it is recording to make the recording process quiet. This does NOT affect the final product.




9. At this point, click PLAY on the VHS to start the video running. Then click : “Start recording.”



10. When the tape ends. Stop the Recording.


11. Then trim the final product to ensure you are getting only the part of the tape that you want to preserve.



12. You do that by moving the triangular start and end points towards or away from each other.

13. Hit “Continue” and Elgato will process the video you have trimmed and place it in **MOVIE** folder on the computer.

Then click on **QUIT**



The VHS tape has been converted and is ready for burning a DVD.

14. Burning the DVD


Find icon of a green toaster on bottom right of task bar. Click on it.




15. This is the main screen in Toast and there are 6 key steps:

1. Name your movie

2. select a style.



3. Click on Media,



DO NOT USE THESE


4. Find your movie
and drag it into space
on the left





5. Select number of copies to be made

6. Hit the Burn button. On next prompt, Insert a blank disc into the small


disk player attached to the
Computer



16. Progress will be posted



17. Take your disc out



18. Click on Red button and then Click on “Don’t save”

